



## Comfort functions



### Pulsation

Massage-like pulsation for RearWash or LadyWash.



### Oscillation

Back and forth movement for RearWash or LadyWash.



### Auto open lid

Short press\*: open/close lid.  
Long press\*\*: activate/deactivate automatic open/close.



### Warm air dryer

Gentle and comfortable warm air drying.



### Night light

Short press\*: turn night light on/off.  
Long press\*\*: activate/deactivate automatic night light.



### Stop

Short press\*: stop all functions immediately.  
Long press\*\*: initiate Stand-By mode.

\* Between 100 ms and 2 seconds  
\*\* Longer than 3 seconds

## Main functions



### Odor Extraction

Short press\*: turn odor extraction on/off.  
Long press\*\*: activate/deactivate automatic odor extraction.



### RearWash

Thorough spray for complete hygiene. Auto-off after 90 sec.



### LadyWash

Extra gentle spray tailored to feminine needs. Auto-off after 90 sec.

## Maintenance functions



### Manual spray wand cleaning

Select manual spray wand cleaning (to be initiated via confirmation button).




### Confirmation button

Initiate manual spray wand cleaning or descaling function (depending on prior selection).



### Descaling function

Select descaling function (to be initiated via confirmation button). Attention! Please reference instructions for use before initiating descaling. Duration: approx. 30 min.



hansgrohe

## LED indicator lights



### Auto open lid LED

Indicates status of auto open lid function when pressing the corresponding button.  
One flash: activated, two flashes: deactivated.



### Battery life LED

Lights up red in case of low battery when pressing any button.



### Descaling reminder LED

Lights up in case descaling is needed when pressing any button. Turns off automatically once the descaling process has been successfully completed.

## Customization functions



### Spray intensity

3 spray intensity settings to choose from (indicated by LED).



### Spray wand position

3 spray wand positions to choose from (indicated by LED).



### Seat heating temperature

4 seat heating temperatures to choose from (indicated by LED).



### Warm air dryer temperature

4 warm air dryer temperatures to choose from (indicated by LED).



### Water temperature

4 water temperatures to choose from (indicated by LED).

# Redefining toilet hygiene.